

Two-Color Calibration of the Zimmerwald SLR System

Werner Gurtner

Astronomical Institute, University of Bern, Switzerland

15th International Laser Ranging Workshop

15–20 October 2006

Canberra


Contents

- Design of the two-color system
- Systematic biases between blue and infrared
- Source of biases
- Measures taken
- Ready for improvement of refraction correction?

Two-Wavelengths Design

- Coudé path optics designed for two wavelengths: 423 nm and 846 nm
- Mirror coatings in telescope optimized for the two wavelengths
- Transmit and receive paths designed for separate beam control (shutters, attenuators, filters)
- Receivers
 - Blue (423 nm): CSPAD (and Hamamatsu PMT)
 - IR (846 nm): Hamamatsu PMT


Transmit Path



Receiving Path

 u^b

b
UNIVERSITÄT
BERN



Conclusions reported 2002

- Range biases between the two reception channels could still be in the system (a few millimeters?)
- *No systematic behavior detectable till now*
- Differences of the Marini–Murray refraction corrections at 423 and 846 nm obviously better than < 8 mm
- Is accuracy of the two wavelengths good enough for mapping function improvement?


But ...

- Systematic and slowly (weeks – months) changing differences between calibrated ranges in blue and infrared (Marini–Murray applied)
- Up to +– 2 cm
- Pass per pass averages of pass residuals (generated during onsite np computation)
- Confirmed by analysis centers

Pass-per-pass bias differences Blue-IR (JCET 2004)

u^b

^b
UNIVERSITÄT
BERN



Time Series of Differences (on-site)

04.2005–03.2006


u^b

b
UNIVERSITÄT
BERN


15th International Laser Ranging Workshop, 15–20 October 2006, Canberra

Pass-Averaged Range Differences "Blue-Infrared"

Lageos 1/2




Comparison of Calibrations with Range Differences




Zoom (4 months)

15th International Laser Ranging Workshop, 15–20 October 2006, Canberra




Internal Calibration



Counter linearity: Short time intervals

ZIMMERWALD COUNTER LINEARITY TEST SETUP




Counter linearity at very short flight times


Stanford Counter Linearity vs. AT-032

◆ Stanford 3113 ■ Stanford 0236


Stanford 0236 Interval (ns)



Event timer, External Calibration




External - Internal Calibration




Reference minus Stanford #3113

Herstmonceux - Stanford 3113
March 2002



Herstmonceux

Counter Differences
A032 ET (3203) - Stanford 3113 (blue Spad)
30-Nov-2005




A032ET Event timer

A032ET Counter Comparison

A032ET 3203-3207

29-Mar-2006



Improving the tropospheric refraction?

$$m_{\Delta R} = f(\lambda_i) / [f(\lambda_2) - f(\lambda_1)] m_{R2-R1}$$

Amplifying factor $f(\lambda_i) / [f(\lambda_2) - f(\lambda_1)]$:

14 for $\lambda_1 = 423$ nm, $\lambda_2 = 846$ nm

$$m_{R2-R1} = \sqrt{m_{R1}^2 + m_{R2}^2 + m_{Cal1}^2 + m_{Cal2}^2}$$

Goal: 1 mm

Calibrated range difference bias-free to 0.08 mm = 0.5 ps!

→ m_{Ri} and $m_{Cali} < 1/14/2mm = 0.04$ mm!!